

BATTERY INSTRUCTIONS:

2 “AA” batteries are included for demonstration and they can be used until replacement. When replacing new batteries, please follow the instructions below:

1. Open the battery compartment cover at the back of controller, discard the included 2 “AA” batteries.
2. Insert 2 fresh “AA” batteries, with positive (+) and negative (–) ends correctly matching the compartment markings.
3. Replace battery compartment cover.

FOR BEST RESULTS:

1. Do not mix old and new batteries.
2. Do not mix alkaline, standard or rechargeable batteries.
3. Use alkaline batteries only.

CAUTION:

Do not dispose batteries in fire. Leakage, explosion and personal injury may occur.