

Section 1: Table of Contents

Section 2: Component Checklist

Section 3: Vehicle Features and Functions

Section 4: Vehicle Features and Functions

Section 5: USB Smart Charge Technology  
Charging the Vehicle

Section 6: Transmitter Battery Installation

Section 7: Transmitter Features and Functions


Section 8: Proper Use  
Precautions and Care

Section 9: Trouble Shooting


Section 10: Cautions

Section 11: Warranty Information

- (1) R/C Vehicle With USB Cord
- (1) Transmitter
- (2) AA Batteries



\* If vehicle pulls to the left or right during forward driving the Steering Trim may need to be adjusted. The Steering Trim is located on TOP of chassis, in between the front wheels.




This product is equipped with USB Smart Charge Technology. The built-in “smart chip” can recognize the power output level of your chosen USB charging device. Charge times will vary between charging devices. Charging from a wall outlet with a USB adapter may be faster than charging from a USB port on a computer. Using Advanced USB Power Delivery, the smart chip will charge the vehicle's internal battery at the fastest speed allowed by your charging device.

### Charging the Vehicle


This vehicle is equipped with an internal Lithium-Ion battery that is recharged via USB. **ON/OFF Switch must be in the OFF position prior to charging.**

1. Locate the ON/OFF switch and USB cord on the under-side of the vehicle.
2. Turn the ON/OFF switch to the “OFF” position.
3. Slide open Storage Compartment cover.
4. Remove USB cable from the Storage Compartment. (Use care when extending cord as it is attached to inside internal battery). Cord can be plugged into any computer or USB outlet adapter (not included).



5. While charging, the LED under the vehicle will be on. Once fully charged the LED will turn off. Charging is completed in approximately 1 - 1.5 hours depending on the type of charging device you use. Return cord and secure storage lid before operating the vehicle.

1. Remove the screw to open the Battery Compartment Cover.
2. Insert 2 “AA” size batteries.  
Make sure the positive (+) and negative (–) markings on the batteries match up to the ones inside the Battery Compartment.
3. Replace the Battery Compartment Cover and replace the screw.



**Note:**  
When replacing Transmitter batteries:  
Do not mix old and new batteries.  
Do not mix alkaline, standard or rechargeable batteries.  
Use alkaline batteries only.

Functions

**Start Engine Sounds Mute ON/OFF**  
Press once to turn on Engine Sounds. Press again to turn off.

**Vapor Effects**  
Press once to emit the vapor effects. Press a second time to stop the effect.

Forward/Reverse Driving

Left/Right Steering

Driving

**This vehicle features 4x4 pivot drive & steering. The unique drive style may take practice to master. Follow the instructions below for some tips.**

**FORWARD/REVERSE DRIVING**


**LEFT/RIGHT TURNING**

**Counter Clockwise**  
**360° SPINS**  
Push and hold joystick as shown for spinning.

**Clockwise**


VERTICAL DRIVING

To raise up onto the back wheels, drive the vehicle in reverse, then quickly push the joystick forward. Once the vehicle is vertical, use the Forward and Left/Right joysticks to continue driving while upright.



ROLLOVER RECOVERY

If vehicle rolls over, rapidly alternate pushing joystick FORWARD, then BACKWARD until vehicle begins to rock. Keep rocking until momentum rolls the vehicle back over.



Filling Water Tank

1. Locate water reservoir plug located on the front of the vehicle chassis. Pull up on the tab to open.

2. Using a measuring cup, measure out 1.25oz. (35ml) of water.

3. Stand vehicle upright, as shown.

4. Place a funnel in the reservoir hole and slowly pour the water into the tank. Be careful not to spill any water.

5. Remove funnel and replace the reservoir plug. Press firmly on the plug to make sure it is secure.

**Note: Do not overfill tank.**

- Over filling can cause spillage.
- Water spillage can damage electronics.
- Measure water before pouring.
- Use funnel to minimize spillage.
- Distilled water recommended to prevent corrosion.

Precautions and Care

Wipe body with a soft rag or cloth.

Do not use chemicals or water to clean

Brush areas where dirt gets trapped.

Switch vehicle OFF when not in use.

Trouble shooting & Support

**Problem - Vehicle does not move or moves slowly.**

- Make certain there are fresh batteries in the transmitter and that they have been installed in the correct position.
- Are the (+) and (-) markings on the batteries in the same position as the (+) and (-) markings in the Transmitter Battery Compartment?
- Are the metal contact tabs touching, rusty or dirty in the transmitter?
- Has the rechargeable Internal Battery been fully charged?
- Make certain that the vehicle ON/OFF switch is in the “ON” position.

**Problem - Vehicle moves by itself or exhibits reduced range from the transmitter.**

- Make certain there are no outside radio interference in your area. The best way to test this is to take the vehicle as far away from radio towers, electrical lines or tall buildings as possible to ensure no further radio interference will occur.

Always remove Batteries from transmitter when not in use.  
Do not dispose batteries in fire. Leakage, explosion and personal injury may occur.  
Do not attempt jumps or tricks with this vehicle.  
Do not attempt to remove internal battery.  
Do not use included USB cord for anything other than its intended purpose.  
Always keep USB cord stored when not in use.  
Adult supervision recommended.

**F.C.C. CAUTION:**  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



OWNER'S MANUAL

Please read and understand all precautions prior to use.

Thank you for choosing a premium New Bright product.

USA & Canada  
30-Day Limited Warranty

New Bright Industries warrants to the original purchaser that this product will be free of defects in materials and workmanship for thirty (30) days from the date of purchase. In the event of such defect within the warranty period, New Bright will repair or replace the product at our sole discretion. This warranty does not cover damage resulting from unauthorized modifications, accident, misuse or abuse.

Should your item have a defect covered under this warranty, first call the toll free number listed below. Most problems can be resolved in this manner. If necessary, you will be issued a Return Authorization (RA) number and instructions on how to obtain a Product Return Form. The Product Return Form is to be used when returning a product to us (postage pre-paid and insured by the consumer).

When returning a defective product, please package the product, the Product Return Form and a copy of the dated sales receipt as proof of purchase. Be sure to mark the RA number on the Product Return Form. If the product is returned without a dated sales receipt, it will be excluded from coverage under this warranty. Please allow 4 to 6 weeks for delivery of repaired or replacement vehicles (depending on your location).

New Bright Industries' liability for defects in materials and workmanship under this warranty shall be limited to repair or replacement at our sole discretion. In no event shall we be responsible for incidental, consequential or contingent damages (except in those states that do not allow this exclusion or limitation).

Valid only in the USA & Canada.

Contact New Bright Industries Customer Service Toll Free at:  
1-877-NBI-TOYS  
(1-877-624-8697)  
Monday through Friday, 8:00 AM to 5:00 PM Eastern Time

U.S. Toy Sales and Marketing Co. Inc.  
30260 Oak Creek Drive – 2nd Floor  
Wixom MI 48393  
1-877-624-8697  
<http://www.newbright.com/>